

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

HOOBS OFFICE D. O. O.
1122 1/2

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL GAS WELL OTHER

2. Name of Operator
American Petrofina Company of Texas

3. Address of Operator
Box 1311, Big Spring, Texas 79720

4. Location of Well
UNIT LETTER G, 1980 FEET FROM THE North LINE AND 1980 FEET FROM
THE East LINE, SECTION 36 TOWNSHIP 12S RANGE 31E NMPM.

7. Unit Agreement Name

8. Farm or Lease Name North Caprock Queen Unit #1

9. Well No. 7

10. Field and Pool, or Wildcat
North Caprock Queen

15. Elevation (Show whether DF, RT, GR, etc.)
4396 GR

12. County
Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Approximate starting date: 6-8-69

- Spot 50 sk cement plug at TD 3023' through 2" EUE tubing using mud laden fluid as displacing medium.
- Cut off 5-1/2" casing at 680' and pull.
- Run 2" EUE tubing to 680' (or 5-1/2" casing stub) and spot 25 sk cement plug.
- Spot 25 sk cement plug at 248' (Bottom of 8-5/8" casing).
- Place 25 sk cement plug in top of 8-5/8" casing and set 4" pipe marker.

10

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE April 28, 1969

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: