

Form 9-331 (May 1963)

UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE (Other instructions on reverse side)

Form approved. Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 060811

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL [X] GAS WELL [] OTHER []

RECEIVED

7. UNIT AGREEMENT NAME

D. Q. S. U.

2. NAME OF OPERATOR Cities Service Oil Company

MAR 30 1970

8. FARM OR LEASE NAME

Tract 1

3. ADDRESS OF OPERATOR Box 69 - Hobbs, New Mexico 88240

9. WELL NO.

4

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 660' FBL and 1980' FEL of

D. C. C. TEXAS, OFFICE

10. FIELD AND POOL, OR WILDCAT

Caprock Queen

Section 15-T14S-R31E Chaves County, New Mexico

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 15-T14S-R31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4424 DF

12. COUNTY OR PARISH

Chaves

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF [] PULL OR ALTER CASING []
FRACTURE TREAT [] MULTIPLE COMPLETE []
SHOOT OR ACIDIZE [] ABANDON* [X]
REPAIR WELL [] CHANGE PLANS []
(Other) []

WATER SHUT-OFF [] REPAIRING WELL []
FRACTURE TREATMENT [] ALTERING CASING []
SHOOTING OR ACIDIZING [] ABANDONMENT* []
(Other) []

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon the above well in the following manner:

- 1. Set CI bridge plug in casing just above open hole.
2. Set 35' cement plug on top of bridge plug.
3. Load hole with mud laden fluid.
4. Cut and pull approx. 2000' of 7" casing.
5. Set 100' cement plug, 1/2 in and 1/2 out of 7" casing stub.
6. Set 100' cement plug at the top of the salt section.
7. Set 100' cement plug, 1/2 in and 1/2 out of the 12 1/2" surface casing stub.
8. Set 10 sack cement surface plug with a 4" dry hole marker.
9. Clean location of all debris and equipment.

RECEIVED MAR 27 1970

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Admin. Supervisor

DATE March 26, 1970

(This space for Federal or State office use)

APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED R. L. BEEKMA

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229
GPO 8 37-499

867-681

RECEIVED

MAR 3 1 1970

OIL CONTROL

MAR 1 1970