

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-11447	
7. Unit Agreement Name	
North Caprock Queen Unit 2	
8. Farm or Lease Name	
Tract # 19	
9. Well No.	
#2	
10. Field and Pool, or Wildcat	
Caprock Queen	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>	North
2. Name of Operator	
Anadarko Production Co.	
3. Address of Operator	
P.O. Box 647 Artesia, New Mexico 88210	
4. Location of Well	
UNIT LETTER <b>L</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>692</b> FEET FROM	
THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>13-S</b> RANGE <b>32-E</b> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	
4403 GL	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Intend to plug and abandon well as follows;

1. Pull tubing and packer.
2. Set cast iron bridge plug at base of 5 1/2" casing approximately 2960'.
3. Spot 25 foot cement plug on top of bridge plug.
4. Knock off oil string at free point, approximately 1200'.
5. Set 25 sack cement plug at casing cut off point.
6. Set 10 sack cement plug at surface.
7. Set surface marker.
8. Remove all equipment and clean up location.

~~No casing will be pulled from well.~~

25 sacks in & out of surface csg. shoe  
Heavy mud between all plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <i>B. J. Curry Jr.</i>	TITLE <i>Secretary Agent</i>	DATE <i>10-28-71</i>
APPROVED BY <i>J. R. Stoney</i>	TITLE <i>SUPERVISOR DISTRICT I</i>	DATE <i>NOV 8 1971</i>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

1 JUL 1971

OIL CONSERVATION CENTER  
1111 11th St.