

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE
(Other Instructions
reverse side)

COPY TO G. C. C.

Form approved.
Budget Bureau No. 42-B1421.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR <u>Tenneco Oil Company</u>		8. FARM OR LEASE NAME <u>Anderson Federal</u>	
3. ADDRESS OF OPERATOR <u>Box 1031 Midland, Texas 79701</u>		9. WELL NO. <u>1</u>	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) <u>At surface</u> <u>1980' FNL + 1980' FEL</u>		10. FIELD AND POOL, OR WILDCAT <u>North Montic W.C.</u>	
14. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <u>Sec. 31, T-14-S, R-35-E</u>	
15. ELEVATIONS (Show whether DF, etc.) <u>4061 DF</u>		12. COUNTY OR PARISH <u>Lea</u>	
		13. STATE <u>NM</u>	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐	WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐	FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒	SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
REPAIR WELL ☐	CHANGE PLANS ☐	(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers, and zones pertinent to this work.)*

8-3-70 (1) Set bridge plug @ 10,300' ± w/ 2 sx cmt. on top.
(2) Cut & recover 5 1/2" casing from 7000' ±.
(3) Set 25 sx plug (cement) over 5 1/2" casing stubb @ 7000' ±.
(4) Set 25 sx cmt plug over 8 5/8" csq shoe @ 4565'.
(5) Cut & recover 8 5/8" csq from 1200' ±.
(6) Set 25 sx cmt plug over 8 7/8" csq stubb @ 1200'.
(7) Set 25 sx cmt plug over 13 3/8" csq shoe @ 430'.
(8) Set 25 sx cmt plug @ surface inside 13 3/8" csq.
(9) Erect Dry hole marker
(10) Clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED L. M. Williams TITLE Prod. Engr

DATE 7-30-70

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED
JUL 31 1970
ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

RECEIVED

AUG 11 1970

OIL CONSERVATION COMM.
HARRIS, R. L.