

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRI
(Other Instructive
verse side)

ATE*
R re

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

AC 048741 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Humble Oil & Refg Co.

3. ADDRESS OF OPERATOR
Box 1600 - Midland Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660 FSL, 660 FNL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

AC. Fepano Federal

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Fumont Vates Rivers

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

S25, T20S, R36E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3558 DF

12. COUNTY OR PARISH

Lea

13. STATE

N. Mex

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Permission is requested to plug and abandon well as follows:

1. Set cmt plug from 3600 - 3855' w/ 60 sack cmt.
2. Set cmt plug from 1800 - 2000' w/ 50 sack cmt if 1900' csq cannot be salvaged. If salvaged cmt w/ 50 sack at csq cut.
3. Cmt plug from 35' to surface w/ 10 sack cmt.
4. Install dry hole marker and clean location.
5. Mud laden fluid between plugs.

- AMENDMENT:**
1. Set additional 20-sack cement plug 2650-2800 feet.
 2. Set 50 sack cement plug 1100-1300 feet or at stub of 3 1/2" casing if higher than 1200 feet. This plug may be substituted for plug No. 2 above if desired.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

Unit Head

DATE

1/17/70

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
JAN 22 1970
ARTHUR R. BROWN

DATE