

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

0+5 NMOCD-Hobbs 1-Foreman EF
1-File 1-Laura Richardson-Midland
2-Engr. LM

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-2736	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Injection well		7. Unit Agreement Name
2. Name of Operator Getty Oil Company		8. Farm or Lease Name East Eumont Unit
3. Address of Operator P.O. Box 730, Hobbs, NM - 88240		9. Well No. 72
4. Location of Well UNIT LETTER <u>E</u> , <u>1980</u> FEET FROM THE <u>N</u> LINE AND <u>660</u> FEET FROM THE <u>W</u> LINE, SECTION <u>26</u> TOWNSHIP <u>19S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Eumont
15. Elevation (Show whether DF, RT, GR, etc.) 3611 GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit.
2. TOH w/ tubing and packer.
3. Set CIBP @ 3820' (perfs 3858-3915).
4. Dump 35' cement on plug.
5. Spot 100 sxs cement plug at 1500'.
6. Spot 10 sxs cement plug @ surface.
7. Install permanent marker.

THIS CERTIFICATION MUST BE FILED 24
HOURS PRIOR TO THE STARTING OF
PROPOSED OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D.R. Crockett TITLE Area Superintendent DATE October 19, 1982

APPROVED BY JERRY SEXTON TITLE DATE OCT 21 1982

CONDITIONS OF APPROVAL, IF ANY: