

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-06056
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No. B-244
7. Lease Name or Unit Agreement Name Christmas
8. Well No. 1
9. Pool name or Wildcat Eumont (Y-SR-Q)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3604' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator Lewis B. Burleson, Inc.
3. Address of Operator P.O. Box 2479 Midland, Texas 79702
4. Well Location Unit Letter <u>D</u> : <u>660</u> Feet From The <u>North</u> Line and <u>660</u> Feet From The <u>West</u> Line Section <u>11</u> Township <u>20-S</u> Range <u>37-E</u> NMPM <u>Lea</u> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3604' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Set 5 1/2" cement retainer @ 3480' - Top of 4" liner is 3538'. TAG
- 2) Squeeze perms w/50 sacks cement.
- 3) Circulate 5 1/2" casing with mud laden fluid.
- 4) Perf 5 1/2" @ 2450'. Squeeze w/50 sacks cement. TAG
- 5) Perf 5 1/2" @ 1650'. Squeeze w/50 sacks cement. TAG
- 6) Perf 5 1/2" @ 1440'. Squeeze w/50 sacks cement. TAG
- 7) Set 10 sack plug @ surface
- 8) Install marker. Clean location.

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Wayne Jarvis TITLE Field Superintendent DATE 10-30-01
TYPE OR PRINT NAME Wayne Jarvis TELEPHONE NO.

(This space for State Use)

APPROVED BY ORIGINAL SIGNED BY TITLE MANAGER DATE 2001
CONDITIONS OF APPROVAL, IF ANY: