

COPIES RECEIVED		
DISTRIBUTION		
OFFICE		
FOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
A-2614	

SUNDRY NOTICES AND REPORTS ON WELLS  
DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. Well <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> Plug & Abandon
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>770</u> FEET FROM THE <u>West</u> LINE, SECTION <u>14</u> TOWNSHIP <u>22S</u> RANGE <u>36E</u> NMPM.

7. Unit Agreement Name
8. Farm or Lease Name McDonald WN State
9. Well No. 25
10. Field and Pool, or Wildcat Jalmat Yates 7Rivers
12. County Lea

15. Elevation (Show whether DF, RT, GR, etc.) 3537' RKB
--

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 3650', PBD 3641'. Present Perfs 3302-3472'.  
Propose to plug and abandon in the following manner:

1. Rig up, install BOPs & POH w/completion assy.
2. RIH w/retr & set @ 3275'. Cmt below retr w/100 sx Cl C cmt.
3. Load hole w/9# mud.
4. Cut & recover 4 1/2" csg from free point.
5. Run tbg & spot 35 sk cmt plug half in & half out of 4 1/2" csg stub.
6. Spot 35 sk cmt plug above top of salt @ 1600'.
7. Spot 35 sk cmt plug @ 7-5/8" csg shoe @ 403'.
8. Spot 10 sk cmt plug @ surface.
9. Erect dry hole marker. Clean & level location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge.

SIGNED <u>[Signature]</u>	TITLE <u>Dist. Drlg. Supv.</u>	DATE <u>4/17/75</u>
APPROVED BY <u>Joe D. [Signature]</u>	TITLE <u>SUPV. [Signature]</u>	DATE <u>4/17/75</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 17 1976

OIL CONSERVATION BOARD  
HOBBS, N. M.