

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

O+5 - NMOCD - Hobbs

1 - Foreman CK

1 - Laura Rich.

1 - Engr. Jim

1 - File

Form C-103
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Getty Oil Company	8. Farm or Lease Name West Jal Delaware
3. Address of Operator P.O. Box 730 Hobbs, NM 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>J</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>17</u> TOWNSHIP <u>25S</u> RANGE <u>36E</u> NMPM.	10. Field and Pool, or Wildcat West Jal Delaware
15. Elevation (Show whether DF, RT, GR, etc.) 3138' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit, install BOP and pull tubing.
2. Set CIBP @ + 7850' with 25' cement on top.
3. Cut 7: casing @ + 6800' and pull.
4. Spot cement plug 6850-6750' over cut 7" casing.
5. Spot cement plug 5300-5150 over 9 5/8" shoe @ 5231'.
6. Spot cement plug 3270-3370, 1350-1450, top and base of salt.
7. Place 10 sx. surface plug.
8. Install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Eddie Seay TITLE Area Superintendent DATE March 29, 1983

APPROVED BY OIL & GAS INSPECTOR TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

MAR 31 1983