

Submit 1 Copy To Appropriate District
Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.	30-025-44070
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	Thistle Unit
8. Well Number	160
9. OGRID Number	6137
10. Pool name or Wildcat	Triple X; Bone Spring (59900)
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	3710'

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Devon Energy Production Co. LP

3. Address of Operator
333 W. Sheridan Ave OKC, OK 73102

4. Well Location
Unit Letter C : 335 feet from the North line and 1430 feet from the West line
Section 22 Township 23S Range 33E NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3710'

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: Conductor P&A ☒

SUBSEQUENT

REMEDIAL WORK
COMMENCE DRILLING OPNS
CASING/CEMENT JOB
OTHER:

INT TO P&A DM
P&A NR _____
P&A R _____

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Devon Energy respectfully requests the following procedure to plug and abandon set conductor:

1. Pump cement job to completely fill conductor with cement
2. Cut off casing 55" below GL
3. Weld plate to cutoff casing. Plate needs to include the following information:
 - a. Company name, Well Name and Number, API Number, & Legal Description
4. Take GPS measurement of plate location
 - a. Can be taken with a hand-help GPS (does not need to be certified or done by a surveying company)
 - b. Take picture of GPS coordinate and plate
 - i. Send to engineer to be stored in well file for this well
5. GPS coordinate information / picture will be given to regulatory to file with C-103 (plug and abandon report)
 - a. Upon completion of drilling / completion, regulatory will file C-103, NMOC will inspect location, bond on well will be released
6. Fill cellar with caliche
7. Get post job cement report from cement vendor

NOTIFY OCD 24 HOURS PRIOR TO
BEGINNING PLUGGING OPERATIONS

Spud Date:

11/20/17

Rig Release Date:

11/20/17

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rebecca Deal TITLE Regulatory Analyst DATE 7/31/2018

Type or print name Rebecca Deal E-mail address: rebecca.deal@dvn.com PHONE: 405-228-8429

For State Use Only

APPROVED BY: Mark Whitaker TITLE P.E.S. DATE 07/31/2018

Conditions of Approval (if any):

C103 INTENT TO P&A EXPIRES
1 YEAR FROM DATE OF APPROVAL