

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.  
OG-961

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator J. C. BARNES OIL CO.	8. Farm or Lease Name HUMBLE "C" STATE
3. Address of Operator PROD. BOX-505, MIDLAND, TEXAS 79701	9. Well No. 2
4. Location of Well UNIT LETTER <del>E</del> 660' FEET FROM THE SOUTH LINE AND 1980' FEET FROM THE EAST LINE, SECTION 34 TOWNSHIP 10-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat INBE (PERMO PENN.)
15. Elevation (Show whether DF, RT, GR, etc.) 4191' B. L.	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. SET A CIBP W/20' CEMENT AT 9000'.
2. SPOT A 25 SX CEMENT PLUG AT 4 1/2" CSG. STUB AT 6000'.
3. SPOT A 25 SX CEMENT PLUG AT TOP OF GLORIETTA AT 5290'.
4. SPOT A 25 SX CEMENT PLUG AT 7 5/8" CSG SHOE AT 4000'.
5. SPOT A 25 SX CEMENT PLUG AT 7 5/8" CSG. STUB AT 2000'.
6. SPOT A 25 SX CEMENT PLUG AT 10 3/4" CSG. SHOE AT 1860'.
7. SPOT A 10 SX CEMENT PLUG AT SURFACE W/MARKER.
8. HOLE WILL BE LOADED WITH MUD-LADEN FLUIDS.

*100' plugs  
24 hr. notice*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE PRODUCTION ACCT. DATE 8-17-72

APPROVED BY *[Signature]* TITLE Dist. I, Supv. DATE AUG 23 1972

CONDITIONS OF APPROVAL, IF ANY: