

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-7097	
7. Unit Agreement Name	
8. Farm or Lease Name State "AE"	
9. Well No. 3	
10. Field and Pool, or Wildcat Allison-Penn.	
12. County Roosevelt	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CEPPEN OR TO PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Atlantic Richfield Company
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM <u>West</u> <u>36</u> TOWNSHIP <u>8-S</u> RANGE <u>36E</u> N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 4058' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was temporarily abandoned on 7/23/68. We propose to plug & abandon as follows:

Set DR plug in 415-D packer at 9602' & cap w/2 sx cement.
 Shoot off and recover 5½" casing from free point (estimated 5000' recovery).
 Set 30 sx cement in & out of 5½" stub.
 Set 30 sx cement across 8-5/8" shoe at 4555'.
 Set 10 sx cement in top of well.

Use 9#/gal salt gel mud. 8-5/8" & 11-3/4" casing strings will remain intact. Erect dry hole marker, clear and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ed Sutch TITLE Dist. Drlg. Supervisor DATE 2/10/71

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: