

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> | 7. Unit Agreement Name |
| 2. Name of Operator Southwestern Natural Gas, Inc. | 8. Farm or Lease Name Jones "26" |
| 3. Address of Operator 900 Building of the Southwest | 9. Well No. 2 |
| 4. Location of Well UNIT LETTER N 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 26 TOWNSHIP 7-S RANGE 32-E NMPM. | 10. Field and Pool, or Wildcat |
| 15. Elevation (Show whether DF, RT, GR, etc.) 4440' GR | 12. County Roosevelt |

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

| NOTICE OF INTENTION TO: | | SUBSEQUENT REPORT OF: | |
|--|--|---|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIATION WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOB <input type="checkbox"/> | OTHER <input type="checkbox"/> |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull rods, pump & tbg.
2. Spot 25 sacks cement plug across perf. interval.
3. Determine free point of csg. & shoot csg. off.
4. Pull csg.
5. Spot ~~45~~ 25 sacks cement plug 50' in & out of csg. stub. **25 SXS**
6. Spot ~~20~~ 25 sacks cement plug 1650' - 1750' (surf. csg. shoe). **25 SXS**
7. Spot ~~8~~ 10 sacks plug in surface. **10 SXS.**
8. Remove wellhead & weld steel plate on surface csg.
9. Install dry hole marker.
10. Clean location.

Work to be started on approval of application.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. E. Hendon TITLE Production Engineer DATE October 23, 1969

APPROVED BY [Signature] TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: