

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Lease <input type="checkbox"/>
5. State Oil & Gas Lease No. E-9512
7. Unit Agreement Name None
8. Farm or Lease Name New Mexico "CW" St.
9. Well No. 1
10. Field and Pool, or Wildcat Midway Abo
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator TEXACO Inc.
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER <u>K</u> <u>1983</u> FEET FROM THE <u>South</u> LINE AND <u>1906</u> FEET FROM THE <u>West</u> LINE, SECTION <u>18</u> TOWNSHIP <u>17-S</u> RANGE <u>37-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3810' (D. F.)

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

TEXACO PROPOSES TO DO THE FOLLOWING WORK ON SUBJECT WELL:

1. Run 2 3/8" od tubing and mud up hole.
2. Spot 15 Sx. cement plug on top of stuck 2 3/8" od tubing @ 4271'.
3. Cut off 4 1/2" od casing @ 3200' and pull same.
4. Spot 25 sx. cement plug 50' above and below cut-off.
5. Spot 10' plug at surface.
6. Set 4" marker extending 4' above ground level and clean up location.

35 SXS

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	TITLE Assistant District Superintendent	DATE January 31, 1969
APPROVED BY	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		