

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

3 - NMOCC  
1 - File

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Getty Oil Company</b>	8. Farm or Lease Name <b>Justis McKee Unit</b>
3. Address of Operator <b>Box 249, Hobbs, New Mexico</b>	9. Well No. <b>701</b>
4. Location of Well UNIT LETTER <b>M</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>330</b> FEET FROM THE <b>West</b> LINE, SECTION <b>19</b> TOWNSHIP <b>25S</b> RANGE <b>37E</b> N.M.P.M.	10. Field and Pool, or Wildcat <b>Justis McKee - Ellen.</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3079' D.F.</b>	11. County <b>Lea</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This is a dual well, completed in the McKee and Ellenburger zones. (Ellenburger zone - L. M. Buffington "B" Well #1) It is proposed to plug and abandon well as follows:

1. Mud up well
2. Place a 25 sack cement plug above Baker Model "D" packer at 7,799' or set a Baker "DR" plug in the Model "D" packer at 7,799' and dump 10' cement on top of plug.
3. Place a 25 sack cement plug at 7,250' or set a CIBP at 7,250' and dump 10' cement on top of the plug.
4. If 7" casing is salvaged (from about 2,480') Place a 25 sack plug in and out of 7" casing stub.
5. Place a 10 sack cement plug at surface.
6. Erect surface marker with proper identification.

Note: If 7" casing is not salvaged, skip step No. 4.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By  
SIGNED C. L. WADE TITLE Area Supt. DATE 9-20-71

APPROVED BY Orig. Signed by Joe D. Ramsey TITLE \_\_\_\_\_ DATE SEP 27 1971  
Dist. 1, Supv.

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 27 1971

OIL CONSERVATION COMM.  
HOBBS, N. M.