

Southern District  
 1625 N French Dr, Hobbs, NM 88240  
 Phone: (575) 241-7063

**State of New Mexico  
 Energy, Minerals and Natural Resources Department  
 Oil Conservation Division Hobbs District Office**

**BRADENHEAD TEST REPORT**

Operator Name	API Number
Property Name	Well No.

**7. Surface Location**

UL - Lot	Section	Township	Range	Feet from	N/S Line	Feet From	E/W Line	County
----------	---------	----------	-------	-----------	----------	-----------	----------	--------

**Well Status**

TA'D WELL	SHUT-IN	INJECTOR	PRODUCER	DATE
YES      NO	YES      NO	INJ      SWD	OIL      GAS	

**OBSERVED DATA**

	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Cspg	(E)Tubing
Pressure					
<b>Flow Characteristics</b>					CO2 ___ WTR ___ GAS ___ Type of Fluid Injected for Waterflood if applies
Puff	Y / N	Y / N	Y / N	Y / N	
Steady Flow	Y / N	Y / N	Y / N	Y / N	
Surges	Y / N	Y / N	Y / N	Y / N	
Down to nothing	Y / N	Y / N	Y / N	Y / N	
Gas or Oil	Y / N	Y / N	Y / N	Y / N	
Water	Y / N	Y / N	Y / N	Y / N	

Remarks – Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

Signature:	OIL CONSERVATION DIVISION
Printed name:	Entered into RBDMS
Title:	Re-test
E-mail Address:	
Date:	Phone:
	Witness:

INSTRUCTIONS ON BACK OF THIS FORM

# PERFORMING BRADENHEAD TEST

## General Procedure for Bradenhead Test

Identify: All valves prior to testing

Gauges: Install on each casing string to record pressure.

Assure: That all valves are in good working condition and **closed at least 24 hours prior to testing.**

Open: Each valve (Bradenhead, intermediate and casing valves) is to be opened separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

- Blow or Puff Yes or No
- Bled down to Nothing Yes or No
- Steady Flow Yes or No
- Oil or Gas Yes or No
- Water Yes or No

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

In case of pressure:

1. Record pressure reading on gauge.
2. Bleed and note time elapsed to bleed down.
3. Leave valve open for additional observation.
4. Note any fluids expelled.

In absence of Pressure:

1. Leave valve open for additional observation.
2. Note types of fluids expelled.
3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.

Sante Fe Main Office  
Phone: (505) 476-3441

General Information  
Phone: (505) 629-6116

Online Phone Directory  
<https://www.emnrd.nm.gov/ocd/contact-us>

**State of New Mexico**  
**Energy, Minerals and Natural Resources**  
**Oil Conservation Division**  
**1220 S. St Francis Dr.**  
**Santa Fe, NM 87505**

CONDITIONS

Action 448471

**CONDITIONS**

Operator: WALSH & WATTS INC 155 Walsh Drive Aledo, TX 76008	OGRID: 24558
	Action Number: 448471
	Action Type: [UF-BHT] Bradenhead Test (BRADENHEAD TEST)

**CONDITIONS**

Created By	Condition	Condition Date
robert.asher	None	1/27/2026