

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-007-20081
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name Van Bremmer Canyon 3018	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Coal Methane	8. Well No. 241-M		
2. Name of Operator Pennzoil Exploration & Production Company	9. Pool name or Wildcat Wildcat		
3. Address of Operator P.O. Box 2967, Houston, Tx 77252			
4. Well Location Unit Letter M : 607 Feet From The West Line and 409 Feet From The South Section 24 Township 30N Range 18E NMPM Colfax County			
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 7831 GR			

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8/12/91 Estimated start of work.

1. Remove surface equipment, pull rods and tubing.
2. Set CIBP @ 1890' with 2 sks (18') class A @ 15.6 ppg on plug.
3. Set CIBP @ 1450' with 12 sks (108') class A cement @ 15.6 ppg on plug. Fill to surface with Gel mud.
4. Place 6 sks (50') surface plug with class A @ 15.6 ppg.
5. Place well marker, fill pits, remove junk and debris from location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE L. D. Williamson TITLE Operations Superintendent DATE 7/09/91

TYPE OR PRINT NAME L. D. Williamson

TELEPHONE NO. 876-2817

(This space for State Use)

APPROVED BY [Signature] DISTRICT SUPERVISOR DATE 7-10-91

CONDITIONS OF APPROVAL, IF ANY: