

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

| | |
|------------------------|-------------------------------------|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | <input checked="" type="checkbox"/> |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

| | |
|--------------------------------|---|
| 5a. Indicate Type of Lease | |
| State <input type="checkbox"/> | Fee <input checked="" type="checkbox"/> |
| 5. State Oil & Gas Lease No. | |
| 7. Unit Agreement Name | |
| 8. Farm or Lease Name | |
| Latigo Ranch, Blk. "C" | |
| 9. Well No. | |
| 1 | |
| 10. Field and Pool, or Wildcat | |
| Wildcat | |
| 12. County | |
| Guadalupe | |

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL ☐ GAS WELL ☒ OTHER-

Name of Operator

Trans Pecos Resources, Inc.

Address of Operator

One Allen Ctr., Suite 2700, 500 Dallas St., Houston, Tx.

Location of Well

UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM
THE West LINE, SECTION 4 TOWNSHIP 9N RANGE 23E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

4994' GL, 4982' KB

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug and abandon within 60 days as follows:

1. Load hole with fresh water, unseat packer, and POH with tubing.
2. Set CIBP at ± 6700 ft. with 50 ft. of cement (w/2% CaCl_2) on top.
3. Load hole with fresh water.
4. Set 10-sack cement plug at surface.
5. Cut off casings at 3 ft. below ground level, weld on plates, and set dry-hole marker.
6. Clean up location, grade location and pits to approximate natural contours.

hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed [Signature] Title Consultant Date 2-5-86

(This space for State Use)

APPROVED BY [Signature] TITLE DISTRICT SUPERVISOR DATE 2-13-86

CONDITIONS OF APPROVAL, IF ANY: