

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO REOPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Trans Pecos Resources, Inc.	3. State Oil & Gas Lease No.
3. Address of Operator One Allen Ctr., Suite 2700, 500 Dallas St., Houston, Tx.	7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>F</u> <u>1680</u> FEET FROM THE <u>North</u> LINE AND <u>1904</u> FEET FROM THE <u>West</u> LINE, SECTION <u>6</u> TOWNSHIP <u>9N</u> RANGE <u>24E</u> UNPM.	8. Farm or Lease Name Latigo Ranch, Blk. "B"
	9. Well No. 2
	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, CR, etc.) 4801' GL, 4813' KB	12. County Guadalupe

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug and abandon within 60 days as follows:

1. Blow down tubing and casing, load hole with fresh water, and POH with tubing.
2. Set CIBP at  $\pm$  6700 ft. with 50 ft. cement (w/2%  $\text{CaCl}_2$ ) on top.
3. Load hole with fresh water.
4. Set 10-sack cement plug at surface.
5. Cut off casings at 3-ft. below ground level, weld on plates, and set dry-hole marker.
6. Clean up location, grade location and pit to approximate natural contours.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed [Signature] Title Consultant Date 2-5-86

(This space for State Use)

APPROVED BY [Signature] TITLE DISTRICT SUPERVISOR DATE 2-13-86  
CONDITIONS OF APPROVAL, IF ANY: