

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
1. Name of Operator Trans Pecos Resources, Inc.		
2. Address of Operator One Allen Ctr., Suite 2700, 500 Dallas St., Houston, Tx.		
3. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>1312</u> FEET FROM <u>East</u> THE LINE, SECTION <u>26</u> TOWNSHIP <u>10N</u> RANGE <u>23E</u> UNPM.		

7. Unit Agreement Name
8. Farm or Lease Name Latigo Ranch, Blk. "D"
9. Well No. 1
10. Field and Pool, or Wildcat Wildcat
12. County Guadalupe

15. Elevation (Show whether DF, RT, GR, etc.)
4810' GL,

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug and abandon within 60 days as follows:

1. Set CIBP at \pm 7350 ft. with 50 ft. of cement (w/2% CaCL₂) on top.
2. Load hole with fresh water.
3. Set 10-sack cement plug at surface.
4. Cut off casings at 3 ft. below ground level, weld on plates, and set dry-hole marker.
5. Clean up location, grade location and pits to approximate natural contours.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed [Signature] Title Consultant Date 2-5-86

(This space for State Use)

APPROVED BY [Signature] TITLE ASSISTANT SUPERVISOR DATE 2-13-86

CONDITIONS OF APPROVAL, IF ANY: