

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103,
Supersedes Old
C-102 and C-103
Effective 1-1-65

MAR 8 3 1982

5a. Indicate Type of Lease	State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.		

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator McClellan Oil Corporation 3. Address of Operator P.O. Drawer 730, Roswell, New Mexico 88202 4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>22</u> TOWNSHIP <u>11N</u> RANGE <u>21E</u> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 5091' DF	7. Unit Agreement Name 8. Farm or Lease Name Driggers Fee 9. Well No. 1 10. Field and Pool, or Wildcat Wildcat 12. County Guadalupe
--	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Re-entry of this well has been infeasible due to large amounts of junk encountered in the hole.

We propose to plug and abandon this well in the following manner:

1. Set a 30 sack Class "C" cement plug at 2061' (Depth well was cleaned out to).
2. Set a 30 sack plug at 1760' inside and out of the 9-5/8" stub.
3. Set a 30 sack plug at 270" inside and out of the 13-3/8" casing.
4. Set a 15 sack plug at surface and install a dry hole marker.

All plugs will have heavy salt mud between plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Paul R. Rigdale</u>	TITLE <u>Operations Manager</u>	DATE <u>3/19/82</u>
APPROVED BY <u>Constance</u>	TITLE <u>REGIST</u>	DATE <u>3-23-82</u>
CONDITIONS OF APPROVAL, IF ANY:		