Office Office Minerals	of New Mex	ico Il Resøurces	· .	Form C-103
District I		year - Year	WELL API NO	May 27, 2004
1625 N. French Dr., Hobbs, NM 87240 District II CONSER	NATION	DIVISION2	30-0	115-30493
1301 W. Grand Ave., Artesia, NM 88210	th St. Fran	icis Procd - ARTESIA	5. Indicate Typ	e of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410 Santa	Fe, NM 875	505	STATE	
District IV	10, 1111 075		6. State Oil &	
1220 S. St. Francis Dr., Santa Fe, NM 87505		"If the age to the second	o. State Off &	Jas Lease No.
SUNDRY NOTICES AND REPORTS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (DEEPEN OF	R PLUG BACK TO A	7. Lease Name	or Unit Agreement Name:
PROPOSALS.)			STW 25 State	
1. Type of Well: Oil Well			8. Well Number	
2. Name of Operator			9. OGRID Number	
EOG Resources Inc.). OGIGE INGIN	7377
3. Address of Operator			10. Pool name or Wildcat	
P.O. Box 2267 Midland, Texas 79702			Sand Dunes (Pennsylvanian, Upper)	
4. Well Location				
Unit Letter <u>E</u> : 1980 feet from the	he Nort	h line and	660 feet	from the <u>West</u> line
Section 25 Township	185 R	ange 29E	NMPM	County Eddy
11. Elevation (Sho		R, RKB, RT, GR, etc	c.)	
Pit or Below-grade Tank Application or Closure	3458	· GR	If conthon	nite are used in
Pit type Depth to Groundwater Distance from	nearest fresh v	vater well Dis		pits are used in
1		bbls; Construction	associatio	n with this work a
THE Effect Thickness.	ik. Volume	bbis, Construction	" pit permi	t is required prior
			to constru	iction.
12. Check Appropriate Box to	Indicate _l N	Nature of Notice,	Κερυιι, οι Οι	nei Daia
NOTICE OF INTENTION TO:		SUB	SEQUENT R	EPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABAND	ON 🗷 F	REMEDIAL WORK		ALTERING CASING
TEMPORARILY ABANDON		COMMENCE DRILLI	NG OPNS. 🔲	PLUG AND ABANDONMENT
PULL OR ALTER CASING MULTIPLE COMPLETION		CASING TEST AND CEMENT JOB		
OTHER:		OTHER:		
OTHER: 13. Describe proposed or completed operations. (Clearly sof starting any proposed work). SEE RULE 1103. For recompletion.	state all perti	nent details, and give	•	_
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. F	state all pertion Multiple (nent details, and give Completions: Attach	wellbore diagrar	n of proposed completion
 Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: Drill cut existing CIBPs to 11600'. Tag Set CIBP @ +/- 11225' + 35' cement cap. 	state all pertifor Multiple (nent details, and give Completions: Attach	wellbore diagram	n of proposed completion
 Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: Drill out existing CIBPs to 11600'. Tag Set CIBP @ +/- 11225' + 35' cement cap. Set CIBP @ +/- 11150' + 35' cement cap. 	state all pertifor Multiple (nent details, and give Completions: Attach	vellbore diagram	of proposed completion OCD 24 hrs. prior
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'.	state all perti or Multiple (nent details, and give Completions: Attach	vellbore diagram	n of proposed completion
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'.	state all perti or Multiple (nent details, and give Completions: Attach	vellbore diagram	of proposed completion OCD 24 hrs. prior
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'.	state all pertifor Multiple C	inent details, and give Completions: Attach	vellbore diagram cement on to Notify and belief. I furt	of proposed completion OCD 24 hrs. price any work done.
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'. 7. Spot 15 sx plug from 3386' to 3486'. Ta	state all pertifor Multiple C	est of my knowledge , a general permit	vellbore diagram cement on to Notify and belief. I furt	of proposed completion OCD 24 hrs. price any work done.
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'. 7. Spot 15 sx plug from 3886' to 3486'. Tag I hereby certify that the information above is true and comp grade tank has been/will be instructed or closed according to NMOO	state all pertifor Multiple Constitution of Mu	est of my knowledge , a general permit	wellbore diagram cement on to Notify and belief. I furt or an (attached) y Analyst	of proposed completion OCD 24 hrs. prior ony work done. her certify that any pit or belowalternative OCD-approved plan
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'. 7. Spot 15 sx plug from 3386' to 3486'. Tag I hereby certify that the information above is true and comp grade tank has been/will by finstructed or closed according to NMOOSIGNATURE	state all pertifor Multiple Constitution of Mu	est of my knowledge a general permit	wellbore diagram cement on to Notify and belief. I furt or an (attached) y Analyst	of proposed completion OCD 24 hrs. prior OCD 25/10/07
13. Describe proposed or completed operations. (Clearly of starting any proposed work). SEE RULE 1103. For recompletion. Proposed procedure to P&A: 1. Drill out existing CIBPs to 11600'. Tag. 2. Set CIBP @ +/- 11225' + 35' cement cap. 3. Set CIBP @ +/- 11150' + 35' cement cap. 4. Set CIBP @ +/- 9400' + 35' cement cap. 5. Spot 20 sx plug from 8891' to 9091'. 6. Spot 15 sx plug from 3866' to 3966'. 7. Spot 15 sx plug from 3386' to 3486'. Tag. I hereby certify that the information above is true and comp grade tank has been/will by instructed or closed according to NMOO SIGNATURE Type or print name Stan Wagner	state all pertifor Multiple Constitution of Mu	est of my knowledge , a general permit [Regulator	wellbore diagram cement on to Notify and belief. I furt or an (attached) y Analyst	of proposed completion OCD 24 hrs. prior OCD 25/10/07