

UNITED STATES DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

Artesia

Form approved.
Budget Bureau No. 42-R1424.

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

5. LEASE DESIGNATION AND SERIAL NO.

0397623

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to recomplete wells into a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

RECEIVED

1. OIL WELL GAS WELL OTHER JUN 9 1977

7. UNIT AGREEMENT NAME

2. NAME OF OPERATOR
Tenneco Oil Company

8. FARM OR LEASE NAME

Folk Federal

3. ADDRESS OF OPERATOR
1860 Lincoln St., Suite 1200, Denver, Colorado

9. WELL NO.

#1

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)
At surface

10. FIELD AND POOL, OR WILDCAT

Greyburg/Jackson

1980 FSL & 660 FWL

11. SEC., T., E., M., OR BLEK. AND SURVEY OR AREA

Sec. 17, T17S, R29E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, CR, etc.)

3659 DF

12. COUNTY OR PARISH

Eddy

13. STATE

N. M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)
PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)
REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1. MIRUPU
- 2. Load hole, pump into formation to determine rate and pressure.
- 3. Pump 20 sx. of cement down casing, displace to 1800'.
- 4. Go in hole with tubing to 750'. Spot a 20 sx. plug from 750' to 650'.
- 5. Pull tubing up to 100' and spot a 20 sx. surface plug.
- 6. Cut-off wellhead, install dryhole marker and clean up location according to regulatory agency specifications.
- 7. Will fill all pits and reseed location to your specifications.

RECEIVED

AUG 23 1976

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE Div. General Manager DATE 8-18-76

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

APPROVED
JUN 8 - 1977
R. L. [Signature]
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side