

N. M. O. C. C. COPY  
UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 029395 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Turner "A"

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson OGSA

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

18-17S-31E

12. COUNTY OR PARISH 13. STATE

Eddy

N.M.

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

**RECEIVED**

2. NAME OF OPERATOR

Atlantic Richfield Company ✓

FEB 5 1975

3. ADDRESS OF OPERATOR

P. O. Box 1710, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface

O. G. C.  
ARTESIA, OFFICE

2200/S  
3080' FNL & 1760' FWL (Unit letter K)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3756' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Clean out & Acidize

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

TD 3510'. Completed from open hole 3090-3510'. Propose to clean out and acidize in the following manner:

1. POH w/completion assy. Install BOP.
2. Run bit and clean out to TD @ 3510'.
3. Run Compensated G-R log TD to 1500'.
4. Run tbg & pkr. Set pkr in OH @ approx 3400'.
5. Acidize open hole as indicated by GR-NL w/3000 gals 15% HCL cont'g paraffin solvent. Treat w/scale inhibitor.
6. Swab back acid load.
7. Run completion assy, test and return to production.

**RECEIVED**

JAN 30 1975

U. S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Dist. Drlg. Supv.

DATE 1/29/75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side