

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil & Gas Division

811 S. 1st Street
Artesia, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993
Designation and Serial No.
LCO28793C

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other
2. Name of Operator
Marbob Energy Corporation
3. Address and Telephone No.
P.O. Drawer 217, Artesia, NM 88210
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1980 FNL, 1980 FEL, Sec. 30 T17S, R30E Unit G

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

NM88525X

8. Well Name and No.

Burch Keely Unit # 150

9. API Well No.

30-015-20402

10. Field and Pool, or Exploratory Area

Grbg Jackson SR Q Grbg SA

11. County or Parish, State

Eddy County, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Notify BLM 24Hr Before Starting

1. POH w/ rods & tubing
2. RHH spot 100' plug @ 2700 (perf. 2702 to 3358) * PERF 2680 - 3446'
3. Perf. 4 1/2 @ 840 sqz. 100' plug @ 840 to 740 (base salt 788') WOC TAG
4. Perf. @ 565' sqz. 150' plug (8 5/8 shoe @ 515 top salt 385) woc TAG
5. Perf. @ 60' circulate cmt to surface
6. Cut off well head install dry hole marker

***Set CIBP within 50 to 100 feet above the open perforations and cap with 35 feet of cement;
or

***Set a cement plug which extends to a minimum of 50 feet below to 50 feet above the perforated interval. TAG

**SEE ATTACHED FOR
CONDITIONS OF APPROVAL**

14. I hereby certify that the foregoing is true and correct

Signed *Alexis C. Swoboda*
(This space for Federal or State office use)

Title Agent

Date 03/06/01

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA
Conditions of approval, if any:

Title

PETROLEUM ENGINEER

Date

APR 03 2001

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side