

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-22474
5. Indicate Type of Lease STATE ☐ FEE ☒
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Big Chief Com.
8. Well No. 1
9. Pool name or Wildcat Dublin Ranch Morrow

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL ☐ GAS WELL ☒ OTHER	
2. Name of Operator Dinero Operating Company	
3. Address of Operator P.O. Box 10505 Midland, Texas 79702	
4. Well Location Unit Letter <u>F</u> : <u>1980'</u> Feet From The <u>North</u> Line and <u>1,980'</u> Feet From The <u>West</u> Line Section <u>22</u> Township <u>22</u> Range <u>28</u> East NMPM Eddy County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3,095' GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ PULL OR ALTER CASING ☐ OTHER: ☐	SUBSEQUENT REPORT OF: REMEDIAL WORK ☐ ALTERING CASING ☐ COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐ CASING TEST AND CEMENT JOB ☐ OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

2510' to 2610' TAG
Set plug from surface to 1,000'; set 100' plug @ 2000'; set 100' plug @ 3000'; set 150' plug @ 3800' to 4000' across DV tool; set 100' plug @ 5000'; set 100' plug @ 6000'; set 100' plug @ 7000'; set 100' plug @ 8000'. Set 50' plug below & above perfs @ 9520' to 9523'. Set 50' plug below & above perfs @ 9596' - 9618'. 21' of cement on top of CIBP @ 9700' which is 100' Above TAG

We intend to set this as soon as possible. We have a rig on standby.

* SALT Gel mud consisting of 10" brine w/25# of Gel per barrel must be placed between each plug

* Install Dry hole marker

* Give O.C.D. 24 HRS Notice Prior to Any Work

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Charlie Williams by JB TITLE Production Superintendent DATE 9/18/01

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

APPROVED BY

DATE

CONDITIONS OF APPROVAL, IF ANY: