

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED
OMB No. 1004-0135
Expires July 31, 1996

5. Lease Serial No.
NMNM-18463
6. If Indian, Allottee or Tribe Name
7. If Unit or CA/Agreement, Name and/or No.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
Elm Ridge Resources, Inc.

3a. Address
PO Box 156 Bloomfield, NM 87413

3b. Phone No. (include area code)
505-632-3476

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
900' FNL & 900' FEL Sec. 15-T23N-R8W

8. Well Name and No.

Federal 15 #41

9. API Well No.

30-045-24578

10. Field and Pool, or Exploratory Area

Nageezi Gallup

11. County or Parish, State

San Juan, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Elm Ridge Resources, Inc. plans to Plug and Abandon the above referenced well as follows: Please see attached.

14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Amy Mackey

Title

Production Assistant

Signature

Date

November 29, 2004

THIS SPACE FOR FEDERAL OR STATE USE

Approved by

Original Signed: Stephen Mason

Title

Date

DEC 02 2004

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NMOC

Elm Ridge Resources, Inc. plans to Plug and Abandon the Federal 15-41 as follows:

TO 4704' Plug 1) Set retainer @ 5160'. Pump 60 sks cement sting out and place 2-sks cement on top of retainer. Pull up hole to 4200' reverse 2 tubing volumes. Shut in backside and attempt to establish rate. If well pressures up go to plug #2. If injection is established, place a retainer @ 4190' and pump 15 sks sting out leave 2 sks on top of retainer.

Plug 2) Set 100' balanced plug 3030'-2930'.

Plug 3) Set 100' balanced plug from 2370'-2270'.

Plug 4) Set 100' balanced plug from 1577'-^{1350'}1477'.

Plug 5) Set 100' balanced plug from ^{1134'}970'-870'.

Plug 6) Set 100' balanced plug from 637'-537'.

Plug 7) Set 50' plug at surface.

Cut off well head set 4' dry hole marker with required information on it.