

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE
(Other instructions on reverse side)

Form approved
Budget Bureau No. 42-R1424

DESIGNATION AND SERIAL NO.
N.M. 05946

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
2. NAME OF OPERATOR Benson - Montin - Greer Drilling Corp.		7. FARM OR LEASE NAME Schwerdt feyer	
3. ADDRESS OF OPERATOR Petroleum Center Bldg. Farmington, New Mex.		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980 ft. FNL 1980 ft. FEL Sec 17 T24N R9W SAN JUAN Co. N.M.		10. FIELD AND POOL, OR WILDCAT Bisti	
14. PERMIT NO.		15. ELEVATIONS (Show whether DF, RT, GR, etc.)	
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 17 T24N R9W		12. COUNTY OR PARISH SAN JUAN	
13. STATE N.M.			

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☒
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

**It is intended to Plug and ABANDON this well
As follows: (This well is Not Capable of Commercial Production)**

1. Squeeze Perfs 5264-5310 w/ 20sx
 2. Cut off and SALVAGE 5 1/2" Csg at free Point.
 3. Spot 20sx plug in an over Stub.
 4. If casing is recovered below 2100 ft. spot 30sx plug 2100 to 2000'
 5. 30sx plug over pc @ 1500 to 1600'
 6. 30sx plug 900 to 1000'
 7. Set P & A marker w/ 10sx Surface Plug.
- Clean Location -**

18. I hereby certify that the foregoing is true and correct

SIGNED **Larry Bedford**

TITLE **Agent for Operator**

DATE **2/3/69**

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

RECEIVED

FEB 4 1969

U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.