

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Bonneville Fuels Corporation

3. Address and Telephone No.

1660 Lincoln, Suite 1800, Denver, CO 80264 (303) 863-1555

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650' FNL, 1650' FEL ^G Sec 15 T27N R11W

5. Lease Designation and Serial No.

SF078094

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Fullerton Fed #2

9. API Well No.

3004506529

10. Field and Pool, or Exploratory Area

West Kutz PC

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Bonneville Fuels Corporation requests permission to permanently plug and abandon the above referenced well following the procedure listed below:

- 1) TOOH w/ 1" tubing.
- 2) Set CIBP @ 2000'. Spot 21 sx cement on top of CIBP (yield: 1.18 cf/sx).
- 3) Perforate 5 1/2" casing @ 1125' to squeeze off Alamo aquifer w/ 90 sx cmt. Displace cmt to 920'.
- 4) WOC. RIH tag plug.
- 5) Perforate 5 1/2" casing @ 166' to squeeze base of 10 3/4" surface casing.
- 6) Set 10 sx cement plug at surface.
- 7) Cut off casing and install dryhole marker per regulations.
- 8) Clean and restore location. Will notify BLM when ready for inspection.

RECEIVED
JUN - 9 1997

OIL CON. DIV.

DIST. 3

14. I hereby certify that the foregoing is true and correct

Signed

Alan L. Morrow

Title

Operations Engineer

Date

5/22/97

(This space for Federal or State office use)

Approved by

/s/ Duane W. Spencer

Title

Date

JUN - 5 1997

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

NMOCD