

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
**Ute Mountain Tribal
Contract 14-20-604-82**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
**Ute Mountain Tribe of
Indians**

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Ute-Indian

9. WELL NO.
10

10. FIELD AND POOL, OR WILDCAT
Verde Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
20-31N-14W N.M.P.M.

12. COUNTY OR PARISH
San Juan

13. STATE
N. Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Empire State Oil Company

3. ADDRESS OF OPERATOR

Box 871 Thermopolis, Wyoming

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FSL & 660' FEL Sec. 20-T31N-R14W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5623 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐ PULL OR ALTER CASING ☐
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐ ABANDON* ☒
REPAIR WELL ☐ CHANGE PLANS ☐
(Other) ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐
FRACTURE TREATMENT ☐ ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐ ABANDONMENT* ☐
(Other) ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Cover open hole section (3150-3272) with cement and bring cement 50 feet up into 4 1/2" casing to 3100.
2. Cut off 4 1/2" casing at lowest free point and pull casing.
3. Set 100 foot cement plug extending from 50 feet down inside casing to 50 feet above cut-off point.
4. Set 50 foot cement plug in bottom surface casing.
5. Set a 10 sack plug in top of surface casing.
6. Erect regulation dry hole marker, clean location and abandon well.

Leave heavy mud between all plugs



18. I hereby certify that the foregoing is true and correct

SIGNED Thomas E. Fenno
Thomas E. Fenno

TITLE **Engineer**

DATE **11-8-66**

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

APPROVED

NOV 14 1966

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.