Budget Bureau No. 1004-0135 UNITED STATES

SUBMIT IN TRIPLICATES

Other instructions on reverse sides? Form 3160-5 (November 1983) Expires August 31, 1985 5. LEASE DESIGNATION AND SERIAL NO. (Formerly 9-331) 14--20--603--65 BUREAU OF LAND MANAGEMENT 6. IF INDIAN, ALLOTTEE OR TRIBE NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.

Use "APPLICATION FOR PERMIT—" for such proposals.) Navajo Tribal 7. UNIT AGREEMENT NAME WELL . WELL X OTHER S. PARM OR LEASE NAME NAME OF OPERATOR Navajo Tribe of Indians "M" Marmac Petroleum 302 2120 So. Holly, Suite 207; Denver, Colo. LOCATION OF WELL (Report location clearly and in accordance with an See also space 17 below.) 10. FIELD AND POOL, OR WILDCAT <u> Horseshoe Gallup</u> OCT 2 0 1988 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA OIL CON. DIV 5--31N--17W 1980' fn1 & 660' fe1 15. ELEVATIONS (Show whether DF, RT, GR. etc. 12. COUNTY OR PARISH 13. STATE 14 PERMIT NO San Juan NM 5299' GR Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data 16. SUBSEQUENT EMPORT OF: NOTICE OF INTENTION TO: REPAIRING WELL PULL OR ALTER CASING WATER SHUT-OFF TEST WATER SHUT-OFF FRACTURE TREATMENT ALTERING CASING MULTIPLE COMPLETE PRACTURE TREAT SHOOTING OR ACIDIZING SHOOT OF ACIDIZE ABANDON* ABANDON MENT (Other) Temporarily Abandon CHANGE PLANS REPAIR WELL (Norm: Report results of multiple completion on Well Completion or Recompletion Report and Log form.) (Other) 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and gones perti-Since we have just become operator on the above lease, we have not had proper time to evaluate if we wish to permanently abandon the above well therefor we would like to temporarily abandon with the following procedure. Surf cgs 7" @ 100' Production cgs 4 1/2" @ 1120 Open Hole 1120 to 1232 Procedure: MI service Rig RIH w/ tbg, displace 25 sx cement 10' above bottom of casing Pull that to top of cement Displace hole w/ 9.2# mud to serface Pull tbg to 100+. Keep hole full of cement Displace 25 sx cement to surface Pull tbg LD tbg Clean up location THIS APPROVAL EXPIRES 18. I hereby certify that the foregoing to true and correct DATE _10/10/88 TITLE Production Supervisor (This space for Federal or State office use) APPROVED BY CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side