RECENER

Final Abandonment Notice

HORRS

Water Disposal

FORM APPROVED OMB No 1004-0137 Expires March 31, 2007

- 44	The state of the s	-
Form 3160-5 (February 2 505)	UNITED STATES 1 0 2009 DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT	•
	BUREAU OF LAND MANAGEMENT SUNDRY NOTICES AND REPORTS ON WELL	S
	Do not use this form for proposals to drill or to re-ente abandoned well. Use Form 3160-3 (APD) for such propo	e

Lease Serial No. LC031695B If Indian, Allottee or Tribe Name

to re-enter an ich proposals.

Convert to Injection

1.	If Unit or CA/Agreement, Name a	nd/or No.
	NM 71052E	

SUBMIT IN TRI	7. If Unit or CA/Agreement, Name and/or No. NM 71052E							
1. Type of Well Oil Well □ □	✓		8. Well Name and No. Warren Unit B/T WF # 68					
2. Name of Operator ConocoPhillip	9. API Well No.							
3a Address P.O. Box 51810 Midland, Tx 79710		3b. Phone No. (include area code) 432-688-6943		30-025-26210 10. Field and Pool, or Exploratory Area Warren Blinebry/Tubb O&G				
4. Location of Well (Footage, Sec., 7 660 FNL & 660 FEL UL: A of 27-20S-38E	T., R., M., or Survey Description) .	✓ .	-	11. County or Parish, State Lea County, New Mexico				
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA								
TYPE OF SUBMISSION	TYPE OF ACTION							
Notice of Intent Subsequent Report	Acidize Alter Casing Casing Repair Change Plans	Deepen Fracture Treat New Construction Plug and Abandon	Production (State Reclamation Recomplete Temporarily Ab	Well Integrity ✓ Other TA Renewal				

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Plug Back

ConocoPhillips Company respectfully request to renew the TA status for the above referenced well. A valid MIT was run on 1/23/2007 and is on file with the BLM. The well is within the boundary of the Phase I waterflood development and has potential as a water injection well as the waterflood is implemented. It is our intent to identify the use of this well and conversion thereof in 2010.

SEE ATTACHED FOR CONDITIONS OF APPROVAL RUN MIT

good. Reports well Reported as OSI 14. I hereby certify that the foregoing is true and correct Name (Printed/Typed) Title Sr. Regulatory Specialist Donna Williams 12/18/2008 Signature THIS SPACE FOR FEDERAL OR STATE OFFICE USE /s/ JD Whitlock Jr Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease Office which would entitle the applicant to conduct operations thereon. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)



BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
 - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging.
 - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes with a 10% allowable leakoff.
 - c. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- 3. Provides justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned.

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status provided that the operator:

- 1. Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval.
- Describes the temporary abandonment procedure.
- Attaches a clear copy or the original of the pressure test chart.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

Submit Subsequent Report and well bore diagram with all Perforations and CIBP with tops of cement. Well will be approved after successful MIT and subsequent report is submitted. This will be the last TA approval for this well. Submit Plans to recomplete, produce or P&A by December 1, 2009. Warren Unit #68