

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
OG-1316

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator J.M. Huber Corporation	8. Farm or Lease Name T.P. State
3. Address of Operator 1900 Wilco Building, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 22 TOWNSHIP 10-S RANGE 36-E NMPM.	10. Field and Pool, or Wildcat S. Crossroads (Dev.)
15. Elevation (Show whether DF, RT, GR, etc.) 4013 GR	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☒
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RTD 12,260'.
5-1/2" casing set at 12,249' w/500 sx.
Completed open hole 12,249' - 12,260' February 19, 1962 w/Baker Model "N"
Packer set at 12,144'.

Proposed plugging program:

Set 25 sx cement plug on top of Model "N" Packer at 12,144'.
Pull 5-1/2" casing (estimated 7000'). Set 25 sx cement plug on top of
5-1/2" casing stub. Set 25 sx cement plug at base of 8-5/8" casing at 4208'.
Pull 8-5/8" casing (estimated 2000'). Set 25 sx cement plug on top of 8-5/8"
stub. Set 25 sx cement plug in base of 13-3/8" casing at 313'. Put 10 sx
plug in top of 13-3/8" casing.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE District Production Supt. DATE May 5, 1969

APPROVED BY [Signature] TITLE Geologist DATE May 5, 1969
CONDITIONS OF APPROVAL, IF ANY: