

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.  
**02167-A Comm W/**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

**02167.**

7. UNIT AGREEMENT NAME  
**none**

8. FARM OR LEASE NAME  
**Grear**

9. WELL NO.  
**1**

10. FIELD AND POOL, OR WILDCAT  
**Allison - Penn**

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
**Sec. 5, 9-S, 37-R**

12. COUNTY OR PARISH  
**Lee**

13. STATE  
**New Mexico**

1. OIL ☒ GAS ☐  
WELL WELL OTHER

2. NAME OF OPERATOR  
**Great Western Drilling Company**

3. ADDRESS OF OPERATOR  
**Box 1659, - Midland, Texas**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface  
**1980' from the North line and 1980' from the west line of  
Sec. 5, T-9-S, R-37-E, New Mexico**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
**4030 G R**

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
(Other) ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
ABANDON\* ☒  
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐  
FRACTURE TREATMENT ☐  
SHOOTING OR ACIDIZING ☐  
(Other) ☐  
REPAIRING WELL ☐  
ALTERING CASING ☐  
ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

**The Grear #1 has failed as a producer. Great Western Drilling Company proposes the following procedure for abandonment. Load the hole with 10# mud. Place a 25 sack cement plug @ 9600'. Pull (estimated 6000-8000') of 4 1/2" casing. Place a 25 sack cement plug in the stub of this casing. Place a 25 sack cement plug @ 4200'. Pull some 700' of 7 5/8" casing. Place a 25 sack cement plug in the stub of this string. Place 25 sacks at 271' (shoe of the 10 3/4" surface pipe) with a 10 sack plug at the surface. Place a proper marker and make a location cleanup.**

18. I hereby certify that the foregoing is true and correct

SIGNED *O. H. Crews* **O. H. Crews** TITLE **Administrative Coordinator** DATE **9-24-64**

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.