

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT - "FORM C-101" FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/> 5. State Oil & Gas Lease No. B-9638
1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator TEXACO Inc. 3. Address of Operator P. O. Box 728 - Hobbs, New Mexico 88240 4. Location of Well UNIT LETTER K 2311 FEET FROM THE South LINE AND 1979 FEET FROM THE West LINE, SECTION 25 TOWNSHIP 11-S RANGE 32-E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 4329' (DF)	7. Unit Agreement Name - 8. Form or Lease Name NCT-1 New Mexico 'BN' State 9. Well No. 1 2 10. Field and Pool, or Wildcat Moore Devonian 12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>
---	---	---	---

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set a CIBP at 10,450' and spot 35' (4 sx) cement plug on top.
- Load hole with mud (25 sx gel per 100 bbls water).
- Run freepoint, cut 5-1/2" casing and pull. *ADDITIONAL PLUGS MAY BE REQUIRED NOTIFY NMPM FOR THIS INFORMATION*
- Spot 100' (25 sx) cement plug across casing stub, 50' above and 50' below.
- Spot 100' (35 sx) cement plug across intermediate casing shoe at 3518'.
- Spot 100' (35 sx) cement plug at 1700'.
- Spot 10' (4 sx) cement plug at surface.
- Install marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u><i>J. L. Smith</i></u>	TITLE Asst. Dist. Supt.	DATE 4-13-76
APPROVED BY <u><i>Jerry Smith</i></u>	TITLE Dist. 1, Supv.	DATE APR 14 1976
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

APR 14 1976

OIL CONSERVATION COMM.
HEDDERS, H. M.