

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection Well		5. LEASE DESIGNATION AND SERIAL NO. MM 058102
2. NAME OF OPERATOR Coastal States Gas Producing Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 235, Midland, Texas 79701		7. UNIT AGREEMENT NAME Flying "M" (SA) Unit
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface Unit Letter D, 659' from the north line and 662' from the west line		8. FARM OR LEASE NAME Flying "M" (SA) Tr. 1-B
14. PERMIT NO.		9. WELL NO. 124
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4284 GR		10. FIELD AND POOL, OR WILDCAT Flying "M" (SA)
		11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA 33-T98-R33E
		12. COUNTY OR PARISH Lee
		13. STATE N.M.

18. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The subject well is temporarily abandoned. Prior to abandonment, it had become an ineffective San Andres injection well. Waterflood response studies indicate the well would not perform well as a producer. There are no known workover and/or re-completion possibilities. We propose to plug the well as follows:

1. Give the USGS and MDOCC, Hobbs offices, 24 hours prior notice before setting first plug.
2. Spot 100' (or 25 sx. minimum) plug on bottom. Allow 12 hours WOC. Tag top of plug. It must be at least 50' above top perforation at 4424'.
3. Determine casing free point; cut off and pull recoverable casing.
4. Mud up between all cement plugs with a 25 sx. salt gel/100 bbl. brine mixture.
5. Spot 100' cement plug in and out casing stub.
6. Spot 100' cement plug from top of salt at 1870'.
7. Spot 100' cement plug in and out of surface casing bottomed at 270'.
8. Cap at surface with 10 sx. cement plug.

AMENDMENT: Place additional 25-sack cement plug in interval 2900-3000 feet. All above plugs to be placed. If 4 1/2" casing cannot be pulled from below any plug location, place plug inside 4 1/2" casing.

18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE **District Prod. Manager**

DATE **3-4-74**

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED
AS AMENDED
MAR 13 1974

ARTHUR R. BROWN
DISTRICT ENGINEER

ALL INFORMATION CONTAINED HEREIN IS UNCLASSIFIED
DATE 10/1/01 BY 60322 UCBAW/MLL

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.