

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

JUL 20 1 29 PM '66

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-596	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
W. K. Byrom		State A
3. Address of Operator		9. Well No.
P. O. Box 147 - Hobbs, New Mexico 88240		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER P 660 FEET FROM THE South LINE AND 660 FEET FROM		Wildcat
THE East LINE, SECTION 4 TOWNSHIP 10S RANGE 36E NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4021 G. L.		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>	PLUG AND ABANDONMENT	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>		
OTHER	<input type="checkbox"/>		

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

7-18-66: Permission requested to plug and abandon. We will pump a 20 sack plug with 10# brine and mud to cover the perforations from 4898 to 4912. I intend to squeeze 10 sack into the perforation interval. The 2-7/8" casing will then be shot off and a 25 sack cement plug will be placed at this point. We will put a 25 sack cement plug at the top of the salt if the casing doesn't cover it. Also a 25 sack plug at the base of the surface and 10 sack at the top of the surface to hold a 4" x 4" marker. The location will be cleaned and anchor pulled.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

W. K. Byrom

TITLE

Geologist

DATE

7-18-66

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: