

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
OG-498

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
Read & Stevens, Inc.	Aztec
3. Address of Operator	9. Well No.
P.O. Box 2126, Roswell, New Mexico 88201	1
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <u>I</u> , <u>2130</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM	Undesignated
THE <u>East</u> LINE, SECTION <u>15</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
4202.7 GL	Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

4-3-72

Received approval to P&A from OCC via telephone.  
Propose to plug in the following manner:

Set cast iron bridge @ 9500' and cap with 35' of cement.  
Fill hole with good mud.  
Cut 5½" casing and pull.  
Set 35 sk cement plug in 5½" casing stub.  
Set 35 sk cement plug 5300' to 5200'.  
Set 35 sk cement plug in shoe of 8-5/8" casing.  
Set 56 sk cement plug in 8-5/8" casing stub.  
Set 80 sk cement plug in shoe of 12-3/4" casing.  
Set 10 sk cement plug 10' to 0'.  
Install Regulation Marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Emmanuel A. Huen TITLE Agent DATE 4-3-72

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE APR 27 1972  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

APR 20 1972

OIL CONSERVATION DIST. DIV.  
HOBBBS, N. M.