

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

LC 059001X

6. If Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Conoco, Inc.

3. Address and Telephone No.

10 Desta Dr. Ste 100W, Midland, TX 79705

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1425' FNL & 1462' FEL
Sec. 33, T-17S, R-32E

G

7. If Unit or CA, Agreement Designation

8. Well Name and No.

MCA Unit No. 370

9. API Well No.

300252985200

10. Field and Pool, or Exploratory Area

Maljamar Grayburg SA

11. County or Parish, State

Lea

2. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☒ Other

Casing Integrity
Test

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

It is proposed to perform the following operations in order to prepare this well for temporary abandonment:

1. Pull rods and pump from wellbore.
2. Tag well for fill and POOH with tubing.
3. RIG with bit and scraper to 3900'.
4. Set a 5-1/2" retainer at 3870'.
5. Pump 75 sacks of Class "C" cement below the retainer and then dump 25 sacks on top of retainer to form a plug up to 3650'.
6. Perform casing integrity pressure test to 500 psig for 30 minutes.
7. Circulate well with packer fluid.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title Sr. Conservation Coordinator

Date 4/6/93

(This space for Federal or State office use)

Approved by [Signature]

Title FOURTH DISTRICT

Date 4/23/93

Conditions of approval, if any:

ATTACHED

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See instruction on Reverse Side