

COPIES RECEIVED	
TRIBUTION	
FE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. L-1636

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole	7. Unit Agreement Name
2. Name of Operator Earl R. Bruno	8. Farm or Lease Name Southland Royalty St.
3. Address of Operator P. O. Box 5456; Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER G, 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 11 TOWNSHIP 18S RANGE 36 E NMPM.	10. Field and Pool, or Wildcat Arkansas Jct. Queen
15. Elevation (Show whether DF, RT, GR, etc.) GL 3818 KB 3829'	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set 100 ft. cement plug from 4,516 - 4616'
- Load hole with mud.
- Set 100 ft. cement plug inside 4 1/2 " casing from 1,980' to 2,080' opposite top of salt.
- Set 100 ft. cement plug half in and half out of 4 1/2" stub if any 4 1/2" casing is recovered.
- Set 100 ft. cement plug half in and half out (285 - 385) at base of 8 5/8" casing.
- Set 10 sk. cement plug in top of 8 5/8" casing.
- Erect 4" dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Earl R. Bruno TITLE operator DATE 12/14/78

Orig. Signed by
Jerry Sexton

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: Expires 6/18/79

RECEIVED

DEC 15 1978

OIL CONSERVATION COMM.
HOUSTON, TEXAS