

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-031622B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Reed Sanderson Unit

8. FARM OR LEASE NAME

Reed Sanderson

9. WELL NO.

No. 24

10. FIELD AND POOL, OR WILDCAT

Eumont Yates 7 Rivers Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 10, T20S, R36E

12. COUNTY OR PARISH 13. STATE

Lea

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Injection Well

2. NAME OF OPERATOR

Conoco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 460 - Hobbs, NM 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

2310' FSL & 2310' FWL

14. PERMIT NO.

30-025-042

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3595' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

1. MIRU. ND wellhead and NU BOP. Tag top of cement retainer & pull up 2'.

2. Spot 25 sx cement on cement retainer.

* - spot 150' @ TOS @ ±1440' 695

3. Spot cement plug across surface casing shoe and set surface plug: Pump 45 sx
cement to circ. hole and set surface plug in 5-1/2" casing.

4. ND BOP and cut off all casing strings at the base of the cellar. Fill casing
strings from the cement plug to surface with cement.

5. Erect an abandonment marker.

For further technical information contact Tom Boelens at 397-5870.

18. I hereby certify that the foregoing is true and correct

SIGNED W.W. Baker W.W. Baker

TITLE Administrative Supervisor

DATE July 11, 1989

(This space for Federal or State office use)

APPROVED BY Thammy Shaw
CONDITIONS OR APPROVAL, IF ANY:

FOR: CHIEF, MINERAL RESOURCES
TITLE

DATE 7-31-89

*See Instructions on Reverse Side

RECEIVED

AUG 1 1989

HOBBY OFFICE