Submit 3 Copies	State of New Mexico		Form C-103
o Appropriate	Energy, Minerals, and Natural Resources Department		Revised 1-1-89
District Office			
DISTRICT I	OIL CONSERVATION DIVISION		WELL API NO.
O. Box 1980, Hobbs, NM 88240	P.O. Box 2088		30-059-20033
O. Box 1980, Hobbs, NWI 86240			
DISTRICT II Santa Fe, New Mexico 87504-2088		7504-2088	5. Indicate Type of Lease
O. Drawer DD, Artesia, NM 88210			STATE FEE
DISTRICT III			6. State Oil & Gas Lease No.
000 Rio Brazos Rd., Aztec, NM 87410			
SUNDRY NOTICES AND REPORTS ON WELLS			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			7 Y None of Visit Assessment None
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			7. Lease Name or Unit Agreement Name
			PDAYO POME OCO CARANUT
. Type of Well			BRAVO DOME CO2 GAS UNIT
OIL GAS WELL WE	, I	CO2	
			8. Well No.
Name of Operator			
AMOCO PRODUCTION COMPANY			2333-361J
Address of Operator			9. Pool name or Wildcat
P.O. Box 303, AMISTA	D, NEW MEXICO 88410		BRAVO DOME CO2 GAS UNIT
			<u> </u>
Well Location Unit Letter J: 1980 Feet From The South Line and 1980 Feet From The East Line			
Section 36	Township 23N	Range 33E NMI	PM Union County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4913 GR			
Charle Ammonista Day to Indiasta Natura of Nation Dapart, or Other Date			
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF I	NTENTION TO:	SUBSI	EQUENT REPORT OF:
ERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK	ALTERING CASING
_		OOMENOE BRILLING ORKE	BUILD AND ADAMPONING I
EMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPNS	S. PLUG AND ABANDONMENT
ULL OR ALTER CASING	CASING TEST AND CEMENT		JOB
THER:		OTHER:	
2. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)			
SEE RULE 1103.			
MIRUSU, kill well as necessary, NUBOP, release packer, lay down production tubing and packer, run cast iron bridge plug			
with wireline, set CIBP at 2,102 feet, run workstring, displace casing with mud laden fluid, pressure test casing to 500 psi,			
cap CIBP with 3 sacks of cement, pull workstring to 1,746 feet, spot 7 sacks of cement, pull workstring to 30 feet, fill casing			
with cement, NDBOP, cut off wellhead, install PXA marker, RDMOSU, cut off well anchors and clean location.			
hereby certify that the information above is true and complete to the best of my knowledge and belief.			
GNATURE ATTA	Combre TITLE	Field Foreman	DATE 8-18 -99
YPE OR PRINT NAME Damy J. Horson	b		TELEPHONE NO. (505) 374-3010
his space for State Use)			
PROVED BY (T 9) Letture TITLE DISTRICT SUPERVISOR DATE 8/23/99			
ONDITIONS OF APPROVAL, IF ANY	// · · · · · · · · · · · · · · · · · · 		
	/		1