

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	<input checked="" type="checkbox"/>
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- C02 Gas Well	7. Unit Agreement Name
2. Name of Operator AMERADA HESS CORPORATION	8. Farm or Lease Name Wilkinson
3. Address of Operator P.O. Box 2040, Tulsa, Oklahoma 74102	9. Well No. 1
4. Location of Well UNIT LETTER K, 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 4 TOWNSHIP 29N RANGE 31E NMPM.	10. Field and Pool, or Wildcat Wildcat
15. Elevation (Show whether DF, RT, GR, etc.) 6049' GR	12. County Union



16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Plugging Procedure:  
Date work to begin: 5/84  
Surface casing: 9-5/8" 36# set at 367' (cmt. circ)  
Production casing: 7" 20# set at 1138' (cmt. top at 300' by Temp. log)  
PBD: 1100' (w/CIBP) OTD: 3960'  
Current Status: Perfs from 849'-999' squeezed off  
1) Fill casing from 1100' to surface w/Class C Neat cmt. while pulling tbq.  
2) Remove wellhead and install dry hole marker.  
3) Restore location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE District Superintendent	DATE April 23, 1984
APPROVED BY 	TITLE	DATE 5-1-84

CONDITIONS OF APPROVAL, IF ANY: