ubmit 3 Copies	State	of New Mexico	Form C-103
Appropriate	Energy, Minerals, and Natural Resources Department		Revised 1-1-89
strict Office			
ISTRICT I	OIL CONSERVATION DIVISION		WELL API NO.
O. Box 1980, Hobbs, NM 88240	P	CO. Box 2088	30-059-20092
ISTRICT II	Santa Fe, New	Mexico 87504-2088	5. Indicate Type of Lease
O. Drawer DD. Artesia, NM 88210			STATE FEE
ISTRICT III			6. State Oil & Gas Lease No.
000 Rio Brazos Rd., Aztec. NM 87410			
SUNDE	RY NOTICES AND REPOR	RTS ON WELLS	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"			7. Lease Name or Unit Agreement Name
	(FORM C-101) FOR SUCH PROPOS	ALS.)	- BRAVO BOME COO CACABURE
Type of Well			BRAVO DOME CO2 GAS UNIT
OIL WELL	GAS WELL O	THER CO2	
Name of Operator			8. Well No.
AMOCO PRODUCTIO	ON COMPANY		1835-131J
Address of Operator			9. Pool name or Wildcat
P.O. Box 303, AMIS	STAD, NEW MEXICO 88	3410	BRAVO DOME CO2 GAS UNIT
Well Location			
Unit Letter J :	1980 Feet From The	South Line and 1980	Feet From The East Line
Section 13	Township 18	Range 35E N	MPM Union County
	10. Elevation	(Show whether DF, RKB, RT, GR, etc.)	
		4505 GR	
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:			
ERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK ALTERING CASING			
<u>L</u>	<u> </u>		
EMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPI	IS. PLUG AND ABANDONMENT
JLL OR ALTER CASING		CASING TEST AND CEMEN	T JOB
THER:	Γ	OTHER:	
Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)			
SEE RULE 1103.			
MIRUSU, kill well as necessary, NUBOP, release packer, lay down production tubing and packer, run workstring to 2,192			
feet, spot 58 sacks of class C cement, pull workstring, WOC, run workstring, tag cement, cement should be above 2,121			
feet, pressure test casing to 500 psi, displace casing with corrosion inhibited fluid, pull workstring to 1,596 feet, spot 10			
sacks of cement, pull workstring to 30 feet and fill casing with cement, NDBOP, RDMOSU, cut off wellhead, install PXA			
marker, cut off well anchors and clean location.			
iereby certify that the information about	ove is true and complete to the best of	of my knowledge and belief.	
SNATURE /// //	teent	TITLE Field Foreman	DATE 2-29-00
PE OR PRINT NAME Damily J. I	Hotopmb /		TELEPHONE NO. (505) 374-3010
his space for State Use)	9/1	TITLE DISTRICT SUPERN	124000 -1-1-
PROVED BY	Com	THILE MICHINICA SOUTH	DATE 3/9/00
ONDITIONS OF APPROVAL, IF ANY,			