

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		<input checked="" type="checkbox"/>
U.S.G.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease  
State  Fee   
5. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

6. Indicate Type of Well  
OIL WELL  GAS WELL  OTHER-  
Name of Operator  
Trans Pecos Resources, Inc.  
Address of Operator  
One Allen Ctr., Suite 2700, 500 Dallas St., Houston, Tx.  
Location of Well  
UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM  
THE West LINE, SECTION 4 TOWNSHIP 9N RANGE 23E SMPM.

7. Unit Agreement Name  
8. Farm or Lease Name  
Latigo Ranch, Blk. "C"  
9. Well No.  
1  
10. Field and Pool, or Wildcat  
Wildcat  
12. County  
Guadalupe

15. Elevation (Show whether DF, RT, GR, etc.)  
4994' GL, 4982' KB

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
		OTHER <input type="checkbox"/>	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Propose to plug and abandon within 60 days as follows:  
 1. Load hole with fresh water, unseat packer, and POH with tubing.  
 2. Set CIBP at ±6700 ft. with 50 ft. of cement (w/2% CaCl<sub>2</sub>) on top.  
 3. Load hole with fresh water.  
 4. Set 10-sack cement plug at surface.  
 5. Cut off casings at 3 ft. below ground level, weld on plates, and set dry-hole marker.  
 6. Clean up location, grade location and pits to approximate natural contours.

hereby certify that the information above is true and complete to the best of my knowledge and belief.  
 Signed [Signature] Title Consultant Date 2-5-86

(This space for State Use)  
 APPROVED BY [Signature] TITLE DISTRICT SUPERVISOR DATE 2-13-86  
 CONDITIONS OF APPROVAL, IF ANY: