

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. <b>30-021-20209</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name <i>Bravo Dome Carbon Dioxide Gas Unit.</i>
8. Well No. <i>2129-351J</i>
9. Pool name or Wildcat <i>Carbon Dioxide Gas Unit</i>

1. Type of Well:  
OIL WELL  GAS WELL  *CO2* OTHER

2. Name of Operator  
*Amoco Production Company*

3. Address of Operator  
*PO Box 3092; Houston Texas 77253*

4. Well Location  
Unit Letter *J* : *2310* Feet From The *South* Line and *2310* Feet From The *East* Line  
Section *35* Township *T21N* Range *R29E* NMPM *Harding* County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
*5409*

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input checked="" type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

*Propose to:*

- Load wellbore with 2% KCL water. Pull out of hole with packer and tubing.*
- Run in hole with cast iron bridge plug and set at 2200 feet.*
- Spot 10 sacks of class C neat on Cast iron bridge plug. Wait on cement overnight.*
- Load wellbore and pressure test to 500 psi for 30 min. If pressure test fails, authorization to permanently plug and abandon will be pursued.*
- Reg down and move out service Company.*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Mark Randolph* TITLE *ADMIN. ANALYST* DATE *4-12-91*

TYPE OR PRINT NAME *MARK RANDOLPH* TELEPHONE NO. \_\_\_\_\_

(This space for State Use)

APPROVED BY *Ry E Johnson* DISTRICT SUPERVISOR TITLE \_\_\_\_\_ DATE *4-19-91*

CONDITIONS OF APPROVAL, IF ANY: \_\_\_\_\_