Subinit 1 Copy To Appropriate District TION State of New Mexico Office District 1 – (575) 393-6161 1625 N. French Dr., Hobbs, NASS 40 DISTRUCTENERGY, Minerals and Natural Resources District II – (575) 740 NSS 40 DISTRUCTENERGY, Minerals and Natural Resources 1625 N. French Dr., Hobbs, NASS 40 DISTRUCTENERGY, Minerals and Natural Resources District III – (575) 740 NSS 40 DISTRUCTENERGY, MINERALS AND NATURAL RESOURCES 811 S. First St., Artesia, NM 88210 District III – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 Sente Fe, NM 87505	Form C-103
District I – (575) 393-6161	October 13, 2009
OnceSeferenceSeferenceMinerals and Natural ResourcesDistrict I $(575)$ 393-6161 $(575)$ 749 N59 $(575)$ 749 N59District II $(575)$ 749 N59 $(575)$ 749 N59 $(575)$ 749 N59811 S. First St., Artésia, NM 88210 $2.0$ $2010$ OIL CONSERVATION DIVISIONDistrict III $(505)$ 334-6178 $(1220)$ South St. Francis Dr.1000 Rio Brazos Rd., Aztec, NM 87410 $(220)$ South St. Francis Dr.District IV $(505)$ 476-3460Santa Fe, NM 87505	WELL API NO. 30-015-20598
811 S. First St., Antesia, NM 88210	5. Indicate Type of Lease
District III – (505) 334-6178 1220 South St. Francis Dr.	STATE FEE
District IV - (505) 476-3460 Santa Fe, NM 87505	6. State Oil & Gas Lease No.
District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM, ECENED Santa Fe, NM 87505 87505	NM-2933
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	7. Lease Name or Unit Agreement Name ETZ State Unit
PROPOSALS.) 1. Type of Well: Oil Well 🖾 Gas Well 🔲 Other	8. Well Number 100
2. Name of Operator	9. OGRID Number
COG Operating, LLC	229137
3. Address of Operator	10. Pool name or Wildcat
600 W. Illinois Ave, Midland, TX 79701	Grbg Jackson-SR-Q-GRBG-SA
4. Well Location	
Unit Letter <u>B</u> : <u>660</u> feet from the <u>N</u> line and <u>1</u>	
1 0	VMPM County Eddy
11. Elevation (Show whether DR, RKB, RT, GR, etc.	
3673' GR	and all the set of all the set of
12. Check Appropriate Box to Indicate Nature of Notice,	Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK D PLUG AND ABANDON 🛛 REMEDIAL WORK D ALTERING CASING	
	ILLING OPNS. 🔲 P AND A 🛛 🗍
PULL OR ALTER CASING 🔲 MULTIPLE COMPL 🔲 CASING/CEMEN	т јов 🔲
OTHER: OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and	d give pertinent dates including estimated date
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Co	mpletions: Attach wellbore diagram of
proposed completion or recompletion.	
1. Tag CIBP @ 2797. Spot 25 sx cmt @ 2505-2405'.	
2. Set 4 1/2 CIBP @ 2505. Circulate hole w/ mud laden fluid. Pressure test cs	g. Spot 25 sx cmt @ 2505-2405' WOE & TAI
3. Spot 25 sx cmt @ 2100-2000'. (Queen)	
4. Perf & Sqz 30 sx cmt @ 1050-950'. (B/Salt) WOC & TAG 5. Perf & Sqz 80 sx cmt @ <b>580</b> -Surface. (T/Salt & Shoe) ~ <b>530</b> '	
6. Cut off well head, verify cmt to surface, weld on dry hole marker.	
only. eccipt	
	sell bore nding tures and
	weiling of weiling under
	id for plot of Report Web Fde
	Approved for flussing of well bore only receipt Approved for flussing of well bore only receipt Approved for flussing of the receipt of Well Plussing) Approved for flussing when the Report of Well Plussing Lisbuilt under the found to CD Web Page under Lisbuilt approved to the found to
Spud Date: Rig Release Date:	Lister 103 (The follow cater
	Arproved for plussing of well bore only, receipt Arproved for plussing of well bore online receipt Arproved for plussing is recained pending receipt Arproved for plussing is recained pending receipt Report of Well Plussing Report of Well Page under Arbitist main be jound to are annius locd. Statist main be jound to are annius locd. Statist are are and the second to a second t
NELL MUST BE PLUBBED BY 3/20/2018	Approved for pluster of the Report of Web Pass Approved for pluster bond is re- List: 100 (Subsequent Report of Web Pass (List: 100 (Subsequent for Communication) of C. 103 (Subsequent for a communication) (Subsequent for a communication)
I hereby certify that the information above is true and complete to the best of my knowledge	ge and belief.
SIGNATURE Urgail Montgomery TITLE agent	DATE 3-17-17
Type or print name abigail Montgomery E-mail address:	sociates.com PHONE: <u>432-580-716</u>
For State Use Only	PHUNE. 322-200- 1161
APPROVED BY: Jabut 2 By st TITLE COMPLIANCE O	FFICER DATE 3/20/17
Conditions of Approval (if any):	
Form provided b	y Forms On-A-Disk · (214) 340-9429 · FormsOnADisk.com
SEE DETTACHED COA-S	

# CONDITIONS FOR PLUGGING AND ABANDONMENT

## District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water **will not** be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 15. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

- 16. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 17. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open** hole.
- 18. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - I) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 19. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

### DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

### (SPECIAL CASES)

### AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)