

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

OCD-ARTESIA

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

**RECEIVED**

**MAY 17 2006**

**WU-ARTESIA**

1 Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Mack Energy Corporation

3. Address and Telephone No.

P.O. Box 960, Artesia, NM 88211-0960

(505)748-1288

4. Location of Well (Footage, Sec., T. R., M. or Survey Description)

660 FSL & 660 FEL, Sec. 35 T16S R31E

5. Lease Designation and Serial No.

NMLC-029438A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Baxter C Federal #1

9. API Well No.

30-015-05002

10. Field and Pool, or Exploratory Area

Grayburg Jackson SR Q G SA

11. County or Parish, State

Eddy, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other \_\_\_\_\_
- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work )\*

1. Notify BLM 24 hours prior to starting plugging operations.

2. Set CIBP @ 3521' w/35' cement cap, circ hole with mud. ✓

\* 3. Set 100' cement plug from 1000-900'. WOC and tag. - Perf & Squeeze - Tag ✓

4. Set 100' cement plug from 360-260', 50' above and below 8 5/8' shoe. WOC and tag. ✓

5. Set 10 sx surface plug.

6. Install dry hole marker.

Note: TOS @ 600', BOS @ 1900'.

\* Add Plug @ BOS

Perf & Squeeze 100' Cement Plug F/2000-1900' - Tag ✓

**SEE ATTACHED FOR  
CONDITIONS OF APPROVAL**

14. I hereby certify that the foregoing is true and correct

Signed

*Jerry W. Sherrill*

Title

Production Clerk

Date

5/9/2006

(This space for Federal or State office use)

**ORIG. SGD J. DAVID B. GLAN**

Approved by

Conditions of approval, if any:

Title

**PRODUCTION ENGINEER**

Date

**MAY 12 2006**

**MACK ENERGY CORPORATION**  
**Baxter C Federal #1**  
**Sec35 T16S R31E**

