

Submit 3 Copies To Appropriate District Office
District I
1625 N French Dr, Hobbs, NM 88240
District II
1301 W Grand Ave, Artesia, NM 88210
District III
1000 Rio Brazos Rd, Aztec, NM 87410
District IV
1220 S St Francis Dr, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

FEB 13 2009

Form C-103
June 19, 2008

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-21254
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. LG 1443
7. Lease Name or Unit Agreement Name STATE 16
8. Well Number 001
9. OGRID Number 002175
10. Pool name or Wildcat FRONTIER HILS-STRAWN GAS POOL
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3352 GL

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
BETTIS, BOYLE & STOVALL

3. Address of Operator
P.O. BOX 1240, GRAHAM, TX 76450

4. Well Location

Unit Letter O : 660 feet from the SOUTH line and 1980 feet from the EAST line
Section 16 Township 23S Range 26E NMPM EDDY County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

BETTIS, BOYLE & STOVALL HAD APPROVAL TO PLUG AS FOLLOWS PROVIDING THE WORK WAS COMPLETED BY 1/29/09 - WE HAVE NOT BEEN ABLE TO GET A PLUGGER TO COMMIT TO PLUG & WE WOULD REQUEST AN EXTENSION OF TIME TO P&A WELL. WE HAVE SPOKEN WITH BASIC & KEY ABOUT THE PROCEDURE.

1. SET CIBP @ 10,000' WITH 5 SXS CEMENT - 35' MINIMUM.
2. LOAD HOLE WITH MUD.
3. CUT & PULL 4-1/2" CASING @ +/- 8,000'.
4. SPOT 35 SX CEMENT 50' IN AND OUT OF STUB AND TAG.
5. SPOT 35 SX CEMENT @ 6,800'.
6. SPOT 35 SX CEMENT @ 5,300'.
7. SPOT 45 SX CEMENT @ 2,800' AND TAG.
8. SPOT 35 SX. CEMENT @ 650' AND TAG.
9. SPOT 10 SX CEMENT SURFACE PLUG - 60' MINIMUM.
10. CLEAN UP AND PERFORM SURFACE RESTORATION.

**Notify OCD 24 hrs. prior
to any work done.**

Approval Granted providing work
is complete by 3/29/09

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Kim Ligon TITLE REGULATORY ANALYST DATE 02/11/2009

Type or print name KIM LIGON E-mail address: kligon@bbsoil.com PHONE: 940-549-0780
For State Use Only

APPROVED BY: PhD Hankins TITLE Compliance officer DATE 2/16/09
Conditions of Approval (if any):