

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

CLSF  
up

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-005-60504
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2675
7. Lease Name or Unit Agreement Name Amoco State
8. Well No. 1
9. Pool name or Wildcat Wildcat Wolfcamp
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4234' GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator ELK OIL COMPANY
3. Address of Operator Post Office Box 310, Roswell, New Mexico 88202-0310

4. Well Location Unit Letter J : 1980 Feet From The South Line and 1980 Feet From The East Line Section 16 Township 12 South Range 26 East NMPM Chaves County
---

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>


12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug and Abandon well as follows:

- (1) 35 sxs of red cement set at 5000'.
- (2) Circulate casing with mud.
- (3) Cut cast at 4000' and pull.
- (4) Spot 35 sx plug in and out of casing stub.
- (5) Spot 35 sx plug at 2050'.
- (6) Spot 35 sx plug at 1410' at base of 8 5/8" casing.
- (7) Spot 10 sx plug at surface, install 4' X 4' dry hole marker.
- (8) Level and clean location.

RECEIVED  
JUN 20 1995  
OIL CON. DIV.  
DIST. 2

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE  TITLE President DATE 6/19/95  
TYPE OR PRINT NAME Joseph J. Kelly TELEPHONE NO. 505/623-3190

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUM  
DISTRICT II SUPERVISOR

JUL 14 1995

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: